

# Uniq PC 215

## User Manual

version 1.6



This manual was not subject to any language revision.  
This manual or any part of it may not be copied, reproduced or otherwise distributed  
without the publisher's consent.

All rights reserved. Elcom, spoločnosť s ručením obmedzeným, Prešov  
© ELCOM, spoločnosť s ručením obmedzeným, Prešov, 2025

# CONTENTS

INTRODUCTION .....	28
Important notices.....	29
DEVICE CHARACTERISTICS .....	31
Indicator LED meaning.....	34
Connecting peripheral devices .....	34
USING THE DEVICE .....	36
Before using the device.....	37
Switching on .....	37
Logging on to the operating system .....	37
Switching off .....	37
Restarting .....	37
Controlling .....	37
Controlling with the touch panel .....	38
Display and image settings .....	41
Color correction .....	41
Rotating the image by 180° .....	41
Wireless connections .....	42
Connecting and disconnecting a USB device .....	42
MOUNTING AND CARE .....	43
Mounting variantsoftheUniqPC .....	44
Care .....	45
TROUBLESHOOTING .....	46
Whattodo in caseofproblems .....	47
Restoring the operating system in case of its corruption .....	48

# ***INTRODUCTION***

Thank you for choosing the Uniq PC. Before you begin using the device, read these instructions to become familiar with the device's features and functions. Be sure to save this manual for the future use. It will help you solve the problems that might arise. The latest version of the manual is freely available on the web site at [www.elcom.eu](http://www.elcom.eu) in the Support section.

## **IMPORTANT NOTICES**


Please pay attention to the following notices. It will help you avoid possible damage to the device and potential injury which could result from improper use of the device. The damage of the device caused by non-observance of the procedures mentioned in these notices, the legal warranty expires due to improper handling with the product.

- The device must be under permanent supervision while "ON" or in "STAND BY" mode until it is turned "OFF" by the central switch and disconnected from the electrical system.
- If you do not plan to use the device, turn off and unplug the device from source of power. Do not leave the switched on device unattended!
- Use only the power adapter and cable approved by ELCOM. Unauthorized adapters or cables can cause batteries to explode or damage the device.
- Improper adapter connection can seriously damage the device. Any damage caused by misuse is not covered under warranty.
- Do not charge the device when the power cord is damaged or if the electrical outlet is not grounded. This may cause electric shock or fire.
- If the device overheats, starts to smoke, makes strange noises or strange smells, immediately turn off the main power switch and unplug the device.
- Do not bend the power cord or place heavy objects on it. Stepping on the power cord or its disruption with heavy object could result in electric shock or fire.
- During a storm or when the device is out of service for longer, unplug the power adapter from the electrical outlet to prevent electric shock or fire.
- Install the product in a place where it will not be exposed to direct sunlight, unusual changes in temperature (below 0°C and over 45°C) or high humidity. Installation in an unsuitable place could cause damage to the casing and electrical components.

• Procedure for disconnection of the power connector:

1 - Connected connector. 2 - Grab the connector by plastic housing, back pulling of housing release the safety catch and it enable to disconnect power connector strength. 3 - Plastic housing of disconnected connector returns to the starting position itself.

- Upon carrying the product from a cool environment to a warm one, or vice versa, do not switch it on for at least 30 minutes.
- The product should not be operated by a person with wet hands. Water could penetrate to the interior and cause damage to the parts.



- Clean the external surface with a soft, dry cloth. Never use caustic cleaning agents. The use of such chemicals could lead to damage to the product. Do not clean the product with sprayed water and do not submerge the product in water.
- If the product is not working properly, take it to an authorized service center technician. Do not attempt to repair the product yourself. Do not open the product!



- Use only the AC/DC adapter provided or an adapter recommended by an authorized dealer. The use of other types of adapters may result in damage to the adapter or the product. First connect the power cable to the Uniq PC, and only afterwards to the power source! Never disconnect a power cable if the Uniq PC or a connected display is switched on!



- Notice: The adapter is designated for interior use only!
- The use of sharp objects for operating the touch panel can cause serious damage or destroy the touch panel.

- Electronic equipment producing interference, connected in the same power circuit, can cause the improper functioning of the device. In such a case, use special anti-jamming aids recommended by the producer.
- To completely disconnect the device from the electrical network, unplug the AC/DC adapter from its electrical outlet.
- If the device is used in ways different than those described in these instructions, the dealer cannot be responsible for any possible damage that may result.
- A symbol (a crossed-out waste basket) on the product or on its packaging indicates that this product, upon completion of its use, should not be treated as common household waste. Instead it should be handed over to a special take-back scheme for the recycling of electrical equipment and electronic components. By ensuring the proper disposal of this product, you will help preserve natural resources and will help prevent potential negative consequences on the environment and on human health.
- The product contributes to the protection of the environment by using lead-free technology for its production and low electricity consumption during operation.

## CONFORMITY DECLARATION

Uniq PC meets the requirements of the directives for the European Union market. The complete conformity declaration is available on the address of manufacturer: ELCOM, spoločnosť s ručením obmedzeným, Prešov, Jesenná 2695/26, 080 01 Prešov, Slovakia.

Operation of device with built-in WiFi/RFID module is possible under the conditions of the general license issued by the national frequency regulatory body.

Elcom limited company hereby declares that the radio device UniqPC 215 ( QC, Celeron 4305UE, i3-8145UE, i5-1145G7E) is in conformity with Directive 2014/53 / EU.

The full EU Declaration of Conformity is available at this website:

<https://www.elcom.eu/en/support/technical-support/industrial-pc-tablets/uniq-pc-215/612364>

- a) the frequency band or bands in which the radio device operates: Wifi / BT 2.4 GHz, 5 GHz,
- b) the maximum high frequency power transmitted in the frequency band or bands in which the radio device operates: Wifi / BT 15 dBm

Warning: Operation of this device in a residential environment may cause radio interference.

## WARNING:

ELCOM notifies owners of the Uniq PC device, that in case of intervention into the BIOS part and subsequent system damage, the claim for warranty repair will be rejected. An owner will be obligated to refund all costs associated with the device repair.

# ***DEVICE CHARACTERISTICS***

combined with multitouch display, and other devices. All this is hidden in a sleek body with modern appearance, which you can customize to fit any interior or exterior. With its top-quality protection against ingress of liquids and other substances it is also suitable for extreme operating conditions in the industry, while on the other hand also meeting the demands of the medical sector. Its robust construction in several mounting versions and optional configurations make it a computer system, which has vast potential for applications in various environments.

**Figure 7.1 Features of Uniq PC 215**




Table 7.1 Technical parameters and available configurations of the Uniq PC 215

	Uniq PC Celeron J1900	Uniq PC Celeron 4305UE	Uniq PC Core i3-8145UE	Uniq PC Core i5-1145G7E
Operating system	Windows 10 IoT, Windows 10 Pro, Linux	Windows 10 IoT, Windows 10 Pro, Windows 11 IoT, Windows 11 Pro, Linux		
Display	21,5" 1920x1080 (16:9)			
Display type	TFT LCD, LED backlight			
Contrast	1000:1			
Number of colors	16,7 mil.			
Touch panel	Capacitive PCT multitouch			
Processor	Intel Celeron J1900, 2.0 GHz, Turbo 2.42 GHz	Intel Celeron 4305UE, 2.0 GHz, Turbo 2.2 GHz	Intel Core i3-8145UE, 2.2 GHz, Turbo 3.9 GHz	Intel Core i5-1145G7E, 1.8 GHz, Turbo 4.4 GHz
RAM	4/8 GB DDR3L, 1600 MHz	8/16/32/64 GB DDR4, 2133 MHz		16/32/64 GB DDR4, 3200 MHz
Storage	256 GB SSD (standard)	512 GB SSD M.2 (standard), larger volume optional		
Interfaces	1x USB 3.0 2x USB 2.0 2x LAN 1x VGA 1x HDMI 1x RS232 (optional) Audio In/Out (optional)	4x USB 3.2 2x LAN 2x DisplayPort 1x RS232 (optional) Audio In/Out (optional)	4x USB 3.2 2x LAN 2x DisplayPort 1x RS232 (optional) Audio In/Out (optional)	4x USB 3.2 2x LAN 2x DisplayPort 1x RS232 (optional) Audio In/Out (optional)
Wireless connection	WiFi/Bluetooth (optional)			
TPM	TPM1.2	TPM2.0		
Audio	Waterproof speakers			
Mounting	VESA 100			
Dimensions	514 x 308 x 57 mm			
(WxHxD) Ingress	IP 65			
protection Power	17 W			20 W
consumption Power	Adapter AC/DC 230 V - 12V (± 5%), 4000 mA			Adapter AC/DC 230 V - 12V (± 5%), 5800 mA
Weight	6 kg (without stand and adapter)			
Operating temp.	0-40°C			
Humidity	80% at 35°C or lower			
Optional accessories	RFID reader			
EMC	CE			

## Indicator LED meaning

**Table 7.2 Status indication LED**



LED off	device is switched on
LED on	device is switched off
LED on, device is turned off	device is in low power mode

## Connecting peripheral devices

It is possible to connect accessories and different peripheral devices to the Uniq PC. These can be connected directly to Uniq PC ports, which are brought out with cables. Individual ports are described in table on the next page.

In addition to cable interfaces Uniq PC can, according to configuration, contain optional wireless interfaces. Possibilities of network connection similar to RJ-45 connection are offered by optional wireless WiFi interface, which does not need connecting any cables and provides some mobility. Optional Bluetooth interface allows for wireless communication and the transfer of data between external devices supporting this communication standard.

**Table 7.3 Uniq PC connectors (not all generally available, depends on configuration)**

Connector	Description
	Power connector. Power adapter connects here. It is secured against accidental unplugging.
	RJ-45 LAN network connection. Connection to a computer network of the Ethernet type (LAN, Internet connection), supports 10/100/1000 Mbps speeds.
	USB connector. Through them it is possible to connect all standard USB devices which are supported by the operating system. This includes, for example, different keyboards, bar-code scanners, payment terminals, scales, storage devices (USB memory sticks, external discs), sound cards, modems, etc. The number of USB ports available can be increased using a replicator or a so-called USB hub device.
	HDMI connector. Allows digital output of multimedia content from Uniq PC to an external devices equipped with HDMI.
	DVI connector. Allows digital or analog output of picture from Uniq PC to an external display device equipped with DVI.
	VGA connector. Allows analog output of picture from Uniq PC to an external display device equipped with VGA.
	The DisplayPort connector is a digital connector used to transfer uncompressed digital content from a Uniq PC to an external display device equipped with a DP interface.
	Audio connector. Uniq PC has two of them – first (LINE-OUT) for connecting external speakers and second (MIC-IN) for connecting external microphone.

**Figure 7.2 Connectors Uniq PC 215 QC**



**Figure 7.3 Connectors Uniq PC 215 Celeron 4305, i3, i5**



# ***USING THE DEVICE***

## **BEFORE USING THE DEVICE**

Prior to using the device it is necessary to connect the power adapter. Connect the power cable to the power adapter. Connect the power cable plug from the power adapter to the power connector. Plug the power cable into the electrical power outlet (230V, 50 Hz), or electrical system within the range of the adapter.

*Note:* Before using the Uniq PC it is a good idea to look over the sections devoted to methods of controlling the device.

## **SWITCHING ON**

After connecting to the power source, turn on the main power button on the back cover of the device. Then press the operating on/off button on the bottom of the device. The device switches on, which is indicated by the LED on the front of the panel. After performing a quick system test, the operating system is launched.

If you have a version of the device without a pre-installed operating system, it is first necessary to install it – see the documentation for the relevant operating system.

## **LOGGING ON TO THE OPERATING SYSTEM**

The welcome screen of the operating system differs according to its type and version. Depending on the type of the operating system it is possible that your operating system will request the entry of a user name and password for the user account.

Enter the required information for logging on to the user account and press Enter or click the button for logging on. If you are creating your own user account with a password, please remember the password, as without it you will not be able to log on to your account.

*Note:* If during logon procedure the computer does not respond to the touch panel controls, connect an external keyboard and mouse, which will allow you to log on and subsequently calibrate the touch panel according to the process described in the section "Calibrating the touch panel".

## **SWITCHING OFF**

The device can be switched off according to the standard procedure of the operating system, by touching the operating on/off button or by turning off the main power button.

## **RESTARTING**

Restarting the device is possible using the standard procedure in the operating system.

If an emergency restart of the device is needed, touch the operating on/off button until Uniq PC turns off. Then turn it on. With this method of restarting you risk losing any unsaved data of the applications which were open at the time of restarting. This solution should be therefore used only if the operating system stops responding and it is not possible to restart it using the standard method.

## **CONTROLLING**

To control the Uniq PC primarily the built-in touch panel is used, additionally it is possible to attach a standard computer mouse, keyboard or other input device to the Uniq PC through a USB port (or other interface).

The mouse can be used to control the mouse cursor within the operating system. You can use the keyboard when entering text and controlling some elements of the operating system and applications using keyboard

shortcuts. The settings for the mouse and keyboard can be changed in the system settings of the operating system.

Controlling using the touch panel can be used to perform many operations without using keyboard and mouse. The information you need to use the touch panel correctly is presented in the following section.

*Note: The way of controlling with the keyboard, mouse and touch panel may be different according to the type of operating system used and its settings.*

## Controlling with the touch panel

The Uniq PC is equipped with a touch panel which allows you to control the mouse cursor and applications or enter text using the virtual keyboard on the display. The touch panel can be controlled by the touch of the fingers or using a special touch pen (stylus). If you use a keyboard or mouse and at the same time the touch panel to control the computer, the individual methods of controlling will interfere with each other.

*Note: Control the touch panel by gentle pressure of the finger or stylus. Do not use excess pressure or objects with hard and sharp edges for controlling; otherwise you may cause damage to the touch panel or the display.*

## Controlling the mouse cursor with the touch panel

Using the touch panel you can control the mouse functions as follows: Tapping on the screen is the equivalent of left-clicking the mouse – the cursor is shifted to the place of the touch and the object beneath the cursor is selected.

Double-tapping – is the equivalent of double-clicking the left mouse button.

Placing and holding a finger on one spot of the display – is the equivalent of clicking the right mouse button, calling up the context menu. After the menu is displayed, tap on the desired item in the menu while the relevant item is activated.

*Parameters for controlling the mouse cursor can be changed in the dialogue box for setting the touch panel display on the "Setting" card.*

## Using gestures

On operating systems that support multi touch control – among supplied operating systems it's Windows – you can use the advanced touch control options using specific movements of fingers or stylus, so called gestures. Using gestures is possible in Windows in compatible applications to control the scrolling, zooming, rotation and a context menu. Basic gestures are summarized below. Not all gestures must be available in all applications and for all objects.


*Note: To take full advantage of the multi touch support, your operating system and also applications need to support multi touch features. This also means that available gesture controls depend on the software used.*

**Table 8.1 Touch gestures available in Windows**

Gesture	How to perform	Description
Pan	Touch and drag the page with either one finger or two fingers.	Use panning to see another part of a page that has scroll bars. For example when viewing a long document or spreadsheet that doesn't fit in the window. When you pan with one finger, dragging your finger vertically moves the page, while dragging your finger horizontally selects text on the page.

Gesture	How to perform	Description
Zoom	To zoom out, touch two points on the item, and then move your fingers toward each other. To zoom in, touch two points on the item, a larger area, and then move your fingers away from each other.	Use zooming to make an item on the screen larger or smaller. With a picture, zooming in shows a smaller area in more detail; zooming out shows a larger area.
Rotate	Touch two points on the item, and then move the item in the direction that you want to rotate it.	Use rotating to move a picture or other item on the screen in a circular direction (clockwise or counter-clockwise).
Press and tap	Press the item with one finger, then quickly tap with another finger close to the first pressing point, while continuing to press the item with the first finger.	Use press and tap to access the shortcut menu. Press and tap does the same thing as press and hold or right-clicking an item.

**Figure 8.1 Illustrations of gestures available in Windows**



### Entering text using the touch panel

By using an application that shows a virtual keyboard on the display it is possible to enter text by tapping on the virtual buttons depicted. The choice of individual keys is most comfortably handled with the help of the touch panel, but this can also be done using a mouse. Most modern operating systems include a virtual keyboard as a standard component.

The virtual keyboard which is a standard component of the operating system is launched as follows:

**Windows :** In addition to above mentioned of launching a virtual keyboard also so called Tablet PC Input Panel can be used, which can be accessed quickly when needed and is easier to use. To display it, proceed as follows:


1. Right-click the taskbar of Windows (hold down the touch screen in the area). Local menu is displayed.
2. In the local menu, expand "Toolbars" and check the option "Tablet PC Input Panel".
3. The taskbar button appears, which allows launching on-screen keyboard or the possibility of handwriting recognition.

Use: When you want to enter text using the touch panel, after the placing of the text cursor to the desired location, tap the Tablet PC Input Panel button and then you can enter text. In basic setup also the edge of the virtual keyboard window is shown at the left edge of the screen and the keyboard can be “pulled” by sliding your finger from the left edge of the screen towards its center. Depending on touch input settings, virtual keyboard icon is also displayed near input fields after you place the text cursor in them.

When you are done entering text, you can close virtual keyboard’s window. Settings for the text input using the touch panel can be found in the “Tools” at the top of the window.

**TIP:** For greater typing comfort you can adjust the size of the virtual keyboard by dragging its edge.

**Figure 8.2 Displaying the Tablet PC Input Panel**




You can also search for and install other applications providing a virtual keyboard for the operation system used which will better suit your needs.

## DISPLAY AND IMAGE SETTINGS

### Color correction

To adjust the contrast and brightness, press and hold the panel on the desktop until local menu appears (mouse right-click). Then select "Graphics Properties". A window opens with the settings, choose the category "Color enhancement". Then select display for which you want to change settings (the internal display or external display connected to the UniQ PC) and set the gamma correction, brightness, contrast, hue and saturation. Confirm with the OK or Apply button.

**Figure 8.3** Setting the contrast and the brightness



### Rotating the image by 180°

If the device is mounted with the display rotated by 90° or 180° it is also essential to set the desktop rotation properly.

To set the rotation of the displayed image press and hold the panel on the desktop until local menu appears (mouse right-click). Then select "Graphics Properties". A window opens with the settings, choose the category "General settings" and set the "Rotation" to a proper value. Confirm by pressing OK or Apply.

**Figure 8.4 Rotating the image by 180°**



*Note:* In Windows, portion of the settings included in the driver (such as display rotation) is also available from standard system dialogs. It doesn't matter where you change the settings, parameters are system-wide.

## **WIRELESS CONNECTIONS**

If your Uniq PC contains optional WiFi and/or Bluetooth components, you can use them to communicate with other devices supporting these wireless standards. You need to use either built-in operating system functions or special utilities (supplied by communication device vendor together with the driver or by a third party) to create and use connections. Please refer to your operating system or respective device documentation.

## **CONNECTING AND DISCONNECTING A USB DEVICE**

When connecting any equipment to the Uniq PC observe the manufacturer's instructions for the given device. After connection of a USB device to a Uniq PC port, the operating system detects it and if it has a driver available for the device, it will load the driver and the device can then be used. If a driver is not auto- matically available, it is necessary to search for one and install it. Drivers usually can be downloaded from the web site of the manufacturer.

If after connecting and using a USB device you want to disconnect, it is a good idea to remove it safely – first in the operation system (in order that all device operations be completed) and then after notification of the operating system to physically pull out the device's connector. The procedure for safe removal of a device depends on the operating system used. Connecting and disconnecting USB devices when the Uniq PC is switched off is always safe.

*Note:* Not all equipment allows for safe removal of hardware. Safe removal makes sense mainly with equipment which stores data (hard disks, USB memory sticks) and which also use the write buffer. Equipment which is not shown on the list of equipment that can be safely removed can be disconnected without the procedure for safe removal.

# ***MOUNTING AND CARE***

## **MOUNTING VARIANTS OF THE UNIQ PC**

Uniq PC is manufactured with a VESA 100 mount.

### **VESA mount**

VESA is a standardized method of attachment suitable for various devices. Due to its high prevalence and standardization there is a wide range of different stands available, that can be used in various environments in order to ensure easy access to connected devices. VESA mount itself does not allow to change the position

of Uniq PC, all position adjustment options are dependent on a stand.

### **VESA stands**

VESA stands are standard screw attachment and are manufactured in various designs. They usually allow for adjustment of connected device's position. Many types of VESA stands are suitable for placement of Uniq PC on moving supports (in vehicles), as they provide a solid connection between the support and Uniq PC. Furthermore, since the Uniq PC is bolted to the stand, it is to some extent also secured against unauthorized relocation off the range allowed by the stand.

*Note : Maximum length of screw's threaded segment for VESA is 9 mm.*

**Figure 9.1 Different VESA stand types**



a) table stand



b) wall mount



c) wall mount double-arm



d) table stand



e) table dual stand

## **CARE**

Prior to cleaning the device, always switch it off and disconnect it from the power source. For cleaning the external cover use a damp towel made of soft fibers. Do not use caustic cleaning agents or solvents as they can cause damage or discoloration of the cover's plastic casing. For cleaning the surface of the display (the touch panel) use a dry cloth. If the display is very dirty, apply a small amount of a quality product for cleaning LCD displays on the dry dusting cloth. Never apply cleaning solutions directly onto the display. Speaker area can be cleaned using in similar manner using damp towel and if needed with small amount of the suitable cleaning agent. Uniq PC is secured against the ingress of water, but it may not be cleaned by immersion. Prevent the penetration of liquids to the inside of the device as they can cause damage to it.

# ***TROUBLESHOOTING***

## WHAT TO DO IN CASE OF PROBLEMS

If problems occur when using the device that prevent its proper use, please look over this chapter, which will help you solve some common problems. If you do not find the solution to your problem in the table, contact Elcom's technical support team. You'll find contact information on the Web site at [www.elcom.eu](http://www.elcom.eu). If you have problems with the software applications not supplied by the company Elcom, contact the supplier of the relevant application.

Problem	Solution
After pressing the on/off button the computer does not lit switch on.	<p>Check the power adapter connection, the LED on the adapter should be lit – if it is not lit, the problem is either with the electrical socket connection or with the power adapter.</p> <p>If after pressing the button the LED on the front panel does not turn off and the adapter is okay, then the probably a fault in the hardware is involved – contact service.</p>
The computer starts but after initial text messages the operating system does not start (the screen remains black or blue with or without text)	<p><b>WINDOWS:</b> Connect an external keyboard and during starting up of the computer repeatedly press the F8 key. A menu should appear from which it is possible to select System restore to return to the previous state or start the computer in Safe mode, where it is possible to perform settings to remove the problem.</p> <p>Connect an external keyboard and during the computer start up repeatedly press the Delete key. This way you enter the system configuration program, where you can change system settings (Beware: Only do this if you know what you are doing!) or you can set standard system settings by selecting Restore Defaults from the Save and Exit menu.</p> <p>If the above-mentioned procedures fail, you may have the option of re-installing the operating system from the hidden disk partition. The procedure is described below, in the section "Restoring the operating system in case of a malfunction".</p>
No image appears on the display, or the display is too dark or too light.	<p>Press the operating on/off button; the device might be in sleep mode.</p> <p>Increase or lower the value of the brightness via the procedure presented in the section "Setting the contrast and brightness".</p>
Image on the display is deformed or graphic elements are too large or blurred.	<p>Check the settings for the screen resolution in the operating system. For the internal display the resolution should be set to a value of 1920 × 1080.</p>
Computer does not respond to commands from the touch panel, or responds faultily	<p>If it is not possible to control the computer at all, connect an external mouse and use it to launch the tools for calibration and setting of the touch panel. Calibrate the touch panel.</p>
There is no sound during multimedia playback.	<p>Check the sound settings within your media player and your operating system. Sounds could be muted or the volume set to a low value. Check whether the drivers for the soundcard are installed and that correct device is selected for the sound playback.</p>
A connected USB device does not work	<p>Check that the device is not switched off or is not in a power-saving mode.</p> <p>Check that the port to which the device is connected is working correctly – connect a simple device, for example a USB mouse to see if it works properly.</p> <p>Check in the device manual whether it is necessary to install a driver or some other program before it is connected.</p>

## RESTORING THE OPERATING SYSTEM IN CASE OF ITS CORRUPTION

*Note: The presented procedure is valid only for devices supplied with the pre-installed operating system Windows. It is not valid for devices supplied with SSD disk with capacity smaller than 32 GB or without an operating system.*

If the system files of the operating system (OS) are damaged and it is not possible to repair them or if the operating system cannot be started, it is possible to perform a complete restore of the system. The hard disk contains a hidden disk partition on which the installation application for the operating system standardly supplied by the producer is installed. For a complete restore of the operating system, connect a keyboard to a USB port, switch on the device and repeatedly press the F10 key until the logo “elcom - rescue” appears and then the main menu with the options for system restore. This program is controlled using the arrow keys, which serve for navigating in the menus, and the keyboard Enter key, which serves for selection of the highlighted item.

Figure 10.1 System restore menu



Select the language of communication (Slovak or English) and from the main menu select option “2 Full system recovery”.

**Beware!** This operation **deletes all data on the disk** and it is **not possible to recover** the lost data. It is usually possible to backup data even if it is not possible to launch the operating system. If you have valuable data stored on the disk, contact a service organization prior to performing this step.



After confirming the deleting of all data a window is displayed with offering operating systems which can be restored. After selection of an operating system the system will launch installation. It is then necessary to proceed according to the instructions of the operating system.

